

True RMS AC / DC Power Clamp Meter

Model 380940



## Introduction

Congratulations on your purchase of the Extech 380940 True RMS Watt Clamp DMM. This meter combines multimeter and clamp meter functionality in one convenient meter. Careful use of this meter will provide years of reliable service.

### Safety

- 1. **NEVER** exceed the specified voltage/current maximum
- 2. USE EXTREME CAUTION when working with high voltages.
- DO NOT measure voltage if the voltage on the "COM" input jack exceeds 500V above earth ground.
- 4. **NEVER** connect the meter leads across a voltage source while the function switch is in the current mode. Doing so can damage the meter.
- 5. **ALWAYS** discharge filter capacitors in power supplies and disconnect the power when measuring.
- 6. ALWAYS turn off the power and disconnect the test leads before opening the back to replace the fuse or batteries.
- 7. **NEVER** operate the meter unless the back cover and the battery/fuse door are in place and fastened securely.

### International Safety Symbols

	DC Voltage DC Current	$\Lambda$	Refer to explanation in owners manual
$\sim$	AC Voltage AC Current	Â	Dangerous voltage risk of electrical shock
<u> </u>	Ground		Double Insulation

2

# Meter Description

- 1. Conductor under test
- 2. Clamp Jaws
- 3. Jaw trigger Opens the meter jaws
- 4. ZERO button Zeroes the DCA reading
- 5. Positive input jack (for red test lead)
- 6. Function select dial
- 7. HOD button freezes the displayed reading
- 8. MAX/MIN button Press to track and view highest and lowest readings
- 9. LCD Display with function indicators and bargraph
- 10. COM input jack (for black test lead)



## **Function Select Switch**



# Display icons

В	Low battery
DC	Direct current
AC	Alternating current
—	Minus sign
AUTO	Automatic range (frequency only)
MAN	Manual range
ZERO	Zero / Relative function
HOLD	HOLD function
MAX	Highest reading
MIN	Lowest reading
•))	Audible continuity
v	Voltage unit of measure
Α	Current unit of measure
М	Prefix MEGA (millions of units)
k	Prefix KILO (thousands of units)
F0 51	Ohm (unit of measure for resistance and continuity
Hz	Hertz (unit of measure for frequency)

# Bargraph display

The 40 segment bargraph display shown below is a graphical interpretation of the measurement. It is displayed under the display digits on the LCD.

The bars in the bargraph indicate a presence of an electronic signal. The more bars showing, the higher the signal. The digits below the graph help the user see how many bars are showing. If 40 segments are showing, the bars will reach the '40' mark, if 20 bars are showing the bars will reach the '20' mark.

The bargraph is to be interpreted based on the range the meter is in while the measurement is being made. If the bargraph shows 40 segments lit, then the signal is at the highest end of the meter's present range.



4

# Operation

### AC + DC Power Watt Measurements

- 1. Connect the test leads to the voltage source in parallel with the load (refer to diagram).
- 2. Clamp onto one of the wires connected to the load.
- 3. Select the AC or DC voltage range using the function select switch and check the voltage reading.
- 4. Select the AC or DC current range using the function select switch and check the current reading.
- 5. Select the appropriate Watt range using the function select switch.
- 6. Read the KW value on the LCD.



### **AC Current Measurements**

**WARNING**: To avoid electric shock, disconnect the test leads from the meter before making current measurements.

- 1. Set the Function switch to the AC Current position.
- 2. Press the jaw trigger and clamp around a single conductor fully enclosing it. Do not allow a gap between the two halves of the jaw.
- 3. Read the ACA value on the LCD.

### **DC Current Measurements**

**WARNING**: To avoid electric shock, disconnect the test leads from the meter before making current measurements.

- 1. Set the Function switch to the DC Current position.
- 2. Press the DCA zero key to null the meter display.
- 3. Press the jaw trigger and clamp around a single conductor fully enclosing it. Do not allow a gap between the two halves of the jaw.
- 4. Read the DCA value on the LCD.

5

#### **AC Voltage Measurements**

WARNING: To avoid electric shock or damage to the meter, do not make any voltage measurements that exceed the maximum specified.

- 1. Set the Function switch to the AC Voltage position.
- 2. Insert the test leads to the meter as follows: Red lead to "V, I), Hz" terminal; Black lead to the COM input.
- 3. Measure voltage with the pointed end of the test leads. Remember that voltage measurements are made in parallel with the device/circuit under test.
- 4. Read the ACV value on the LCD.

#### DC Voltage Measurements

**WARNING:** To avoid electric shock or damage to the meter, do not make any voltage measurements that exceed the maximum specified.

- 1. Set the Function switch to the DC Voltage position.
- Insert the test leads to the meter as follows: Red lead to "V, 围Hz," terminal; Black lead to the COM input.
- 3. With the pointed end of the test leads measure voltage. Remember that voltage measurements are made in parallel with the device or circuit under test.
- 4. Read the DCV value on the LCD.

#### **Frequency Measurements**

- 1. Set the Function switch to the Hz position.
- 2. Insert the test leads into the meter's input terminals.
- 3. Connect the other ends of the test leads in parallel with the device/circuit under test.
- 4. Read the Frequency measurement on the LCD in Hz.

#### **MIN, MAX Function**

Pressing the MIN/MAX key allows the meter to display ONLY the highest and the lowest readings encountered. Press the MIN/MAX key once to view the minimum reading, press it again to view the maximum reading. Note that the meter will only change its displayed reading when a measurement is taken higher than the previous MAX or lower than the previous MIN readings. The HOLD display icon (along with the MIN or MAX icon) will appear on the LCD in MIN/MAX mode. Pressing the MIN/MAX key a 3<sup>rd</sup> time returns the meter to normal operation.

#### Data Hold

To freeze the current reading on the LCD, press the Data Hold key. To release the Data Hold function and return the meter to normal operation, press the Data Hold key again.

#### **Relative Mode**

- 1. Press the Zero key and the present measurement will Zero.
- All subsequent measurements are displayed with respect to the zeroed reading. For example, if a 20A reading is zeroed and a 30A reading is subsequently measured, the LCD will display 10A.
- 3. To return to normal operation, press and hold the zero key for 2 seconds.
- 4. Note that Relative mode is not available if MIN/MAX mode is enabled.

6

#### Auto Power OFF

To extend battery life, the meter will auto power off after 30 minutes of operation. To resume operation either turn the meter OFF and then ON again or press the HOLD button.

#### **Battery Replacement**

- 1. When the low battery symbol appears on the LCD, the batteries must be replaced.
- 2. Turn the meter off and remove the rear battery compartment screw.
- 3. Lift off the battery compartment cover and replace the two 1.5V AA cells.
- 4. Replace the compartment cover and secure the screw.

X

You, as the end user, are legally bound (**Battery ordinance**) to return all used batteries and accumulators; **disposal in the household garbage is prohibited!** You can hand over your used batteries / accumulators at collection points in your

community or wherever batteries / accumulators are sold!

**Disposal:** Follow the valid legal stipulations in respect of the disposal of the device at the end of its lifecycle

#### Cleaning

Use only a dry cloth to clean the plastic case.

## Specifications

### **General Specifications**

Display	3-3/4 digit (4000 count) LCD with 40 segment bargraph		
Functions	Watts, ACA, DCA, ACV, DCV, Frequency		
Polarity	"-" indicates negative polarity; positive assumed		
Current sensor	Hall effect sensor type		
Overload indication	Left blinking digit		
DCA zero adjust	One touch zero key		
Display rate	2 readings/second (20 readings/second for bargraph)		
Auto Power Off	Meter turns off automatically after 30 minutes		
Battery	Two 1.5V AA batteries		
Operating temp.	-10°C to 50°C (4°F to 122°F)		
Operating Humidity	< 85% RH		
Power consumption	Approximately 10mA DC		
Weight	190g (6.7 oz) including battery		
Dimensions	183 x 63.6 x 35.6mm (7.2 x 2.5 x 1.4") (HWD)		
Jaw opening	23mm (0.9") maximum conductor size		
Standards	IEC 1010 Category III 300V, Category II 600V		

7

### **Range Specifications**

Function	Range	Resolution	Accuracy		Overload protect			
AC Power	40kW	10W	±(1.5% + 3)	±(1.5% + 3dgts)		250V, 400A		
	Note: 50/60Hz, PF 0.6 to 1, Vpeak < 360V							
	240kW	100W	±(1.5% + 3dgts)		600V, 400A			
	Note: 50/60Hz, PF 0.6 to 1, Vpeak < 850V							
	40kW	10W	±(2.5% + 3dgts)		250V, 400A			
	Note: 40Hz to 100Hz, PF 0.6 to 1, Vpeak < 360V							
	240kW	100W	±(2.5% + 3dgts)		60	300V, 400A		
	Note: 40Hz to 100Hz, PF 0.6 to 1, Vpeak < 850V							
DC Power	40kW	10W	±(1.5% + 3dgts)			250V, 400A		
	240kW	100W	±(1.5% + 3dgts)			250V, 400A		
DC Current	400A	100mA	±(1.5% -	±(1.5% + 3dgts)		600A DC		
AC Current			50/60Hz	40 to 100Hz				
True RMS, Crest factor < 4	400A	100mA	±1.5% ±3dgts	±2.5% ±4dgts		600A AC		
DC Voltage	400V	0.1V	±(1.0% -	· 2dgts)		800V DC		
AC Voltage True RMS, Crest factor < 4, Input impedance 10M			50/60Hz	40 to 1	1 kHz			
	600V	1V	±(1.5% + 2dgts)	±(2.0%	+4d)	800V AC		
Frequency	10Hz - 10kHz	0.01- 10Hz	±(0.8% + 2dgts)	Sensitivi	ty 10V	600V AC		

Copyright © 2012 Extech Instruments Corporation (a FLIR company) All rights reserved including the right of reproduction in whole or in part in any form. www.extech.com

8