


Model RH10 Hygro-Thermometer

Humidity and Temperature Meter



Introduction

Congratulations on your purchase of the Extech Hygro-Thermometer Model RH10. This device measures relative humidity and air temperature using the attached probe. The large, easy-to-read backlit LCD includes primary and secondary displays plus status indicators. To conserve battery energy the meter switches OFF automatically after a 30 minute period of inactivity. This device is shipped fully tested and calibrated and, with proper use, will provide years of reliable service. Please visit our website (www.extech.com) to check for the latest version of this User Guide, Product Updates, and Customer Support.

Safety

- The probe extending from the top of the meter houses the sensitive measurement sensors, do not mishandle, shock, or allow liquids to come into contact with it.
- The probe sensor can cause personal injury if it is misused or mishandled. Use caution when handling this device.
- Do not allow children to handle this device or the accessories and packing materials supplied with it.
- The meter uses a 9V battery (installed in the rear battery compartment). Please remove the battery from the meter if the meter is not to be used for a long period of time. Spent batteries that remain in the meter could potentially leak and cause damage to the meter.


Meter Description

Front side of meter

1. Relative Humidity and Air Temperature Probe
2. Power ON/OFF button
3. Backlight ambient light sensor
4. Relative Humidity reading on LCD
5. Air Temperature reading on LCD
6. MAX-MIN button


Rear side of meter

7. Threaded Tripod mount
8. Temperature units select switch access
9. Battery compartment



Display Layout

1. Temperature reading digits
2. Relative Humidity reading digits
3. Low Battery symbol
4. Maximum air temperature and relative humidity measurements
5. Minimum air temperature and relative humidity measurements
6. Relative Humidity unit of measure
7. Temperature units of measure
8. Auto Power OFF reminder clock symbol



Operation

Power

Press the Power  button to switch the meter ON or OFF. If the meter does not switch ON when prompted, check that a fresh 9V battery is installed in the rear battery compartment. To conserve energy, the meter switches OFF automatically after 30 minutes of inactivity.

Relative Humidity and Temperature Measurements

1. Switch the meter ON.
2. Hold the probe in the area to be tested & allow adequate time for readings to stabilize.
3. Read the Relative Humidity measurement in %RH units at the center of the LCD.
4. Read the Air Temperature in degrees C or F on the lower display digits.

NOTE: Do not immerse the probe in liquid; it is intended for use in air only.

°F/°C units selection

1. Ensure that the meter is switched OFF.
2. Open the battery compartment by carefully sliding the rear compartment cover downward.
3. Remove the battery from the compartment. The battery can remain connected to the red/black wires but it must be physically removed from the compartment cavity.
4. The unit of measure can be changed using the surface mount selector switch located on the printed circuit board accessible through an opening in the battery compartment. See the Description section of this manual for the location of the opening.
5. With good lighting, locate the switch visually. Then use a non-conductive screwdriver or other tool to toggle the switch left or right. The switch is labeled in the battery compartment. If the label is removed, move the switch to the left for degrees F and to the right for degrees C.
6. Place the battery back in the compartment as detailed in the battery replacement section.
7. Switch the meter ON and verify that the LCD display shows the desired unit of measure.

MAX-MIN Recording

1. Press the MAX-MIN button to display the highest readings (maximum) recorded. The readings shown will be the highest readings measured since the meter was switched ON. The MAX icon will appear at the top of the LCD.
2. Press the MAX-MIN button again to display the lowest readings (maximum) recorded. The readings shown will be the lowest readings measured since the meter was switched ON. The MIN icon will appear at the top of the LCD.
3. Press the MAX-MIN button again to switch the display back to real time measurement indicator mode. The MAX and MIN icons will switch OFF.

LCD Backlight

The LCD backlight switches ON automatically when the ambient light dims below the threshold. The ambient light sensor is located directly above the LCD window. To test the backlight, cover the ambient light sensor and the LCD backlight should immediately switch ON.

Maintenance

Cleaning and storage

1. Meter housing only: Clean with a damp cloth and mild detergent when necessary. Do not use solvents or abrasives.
2. Do not attempt to introduce liquid into the probe access holes when cleaning. The probe head can be cleaned using a dry, lint free cloth to dust and to free debris from the probe openings.
3. Store the meter in an area with moderate temperature and humidity.

Battery Replacement

The battery symbol appears on the LCD when the 9V battery needs to be replaced. Note that the meter automatically switches OFF after 30 minutes of inactivity to conserve battery energy.

Replace the 9V battery as follows:

1. Switch the meter OFF if necessary.
2. Remove the rear battery compartment cover by sliding the compartment cover downward.
3. Replace the 9V battery carefully.
4. Place the red and black wires cautiously in the battery compartment to avoid crimping when closing the compartment cover.
5. Always re-assemble the meter before operating.



Never dispose of used batteries or rechargeable batteries in household waste.

As consumers, users are legally required to take used batteries to appropriate collection sites, the retail store where the batteries were purchased, or wherever batteries are sold.

Disposal: Do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical and electronic equipment.

Other Battery Safety Reminders

- Never dispose of batteries in a fire. Batteries may explode or leak.
- Never mix battery types. Always install new batteries of the same type.

WARNING: To avoid electric shock, do not operate the meter until the battery cover is in place and fastened securely.

Specifications

Function	Range and Resolution	Accuracy
Humidity	0.0 to 20.0% RH	± 5.0% RH
	20.0 to 80% RH	± 3.5% RH
	80.0 to 95.0% RH	± 5.0% RH
Air Temperature	-20.0 to 60.0°C (-4.0 to 140.0°F)	± 2.0°C (± 3.0°F)

Display	Dual LCD with backlight and status indicators
Accuracy note	Accuracy is specified for the following ambient temperature range: 18 to 28°C (64 to 82°F)
Sampling Rate	2 samples per second
Auto Power OFF	Meter automatically switches OFF after 30 minutes of inactivity
Operating Conditions	0 to 50°C (32 to 122°F); < 80% RH non-condensing
Storage Conditions	-10 to 60°C (14 to 140°F); <80% RH non-condensing
Power Supply	9V Battery
Battery Life	Approx. 150 hours
Dimensions / Weight	135 x 229 x 46mm (5.3 x 9 x 1.8"); 200g (7.0 oz.)

Copyright © 2013 - 2015 FLIR Systems, Inc.

All rights reserved including the right of reproduction in whole or in part in any form

www.extech.com