

Adjustable AC Voltage Detector

 **Non-contact detection of AC Voltage**
Detects down to 12VAC with Sensitivity adjust

Features:

- Non-Contact detection of AC voltage from 12VAC to 600VAC
- Sensitivity adjustment increases or reduces sensor trigger threshold
- Audible and visible voltage indication
- Self test function
- Small size with pocket clip
- Dimensions: 6.1 x 1.1 x 1" (155 x 28 x 25mm)
Weight: 1.5oz (42g)
- Complete with pocket clip and four LR44 button batteries

Applications:

- Detects "live" wires, breaks in wires, and hot side of lines
- Detects live outlets and outlet polarity
- Trace HVAC and security system wires



Ordering Information:

DV30Adjustable AC Voltage Detector

