Impact and Impact Pro

Honeywell





The Impact range of portable multi-gas monitors is able to monitor and display up to four gases simultaneously

Impact Personal multi-gas monitors



- Pre-calibrated plug-in sensor cartridge
- High specification sensors
- Patented Surecell[™] toxic sensors
 Stable and accurate

_ . ..

- Easy to Use
- One button on/off
- Multi-lingual, intuitive menu systemOn screen prompts guide user
- Built-in correction factors for flammable gases
- Minimal training required

Easy to Maintain

- Plug-in operation for all serviceable parts
- Cartridge replacement in less than one minute
- Re-calibration in less than two minutes when
- using EnforcerMinimised cost of ownership

Durable Housing

- Waterproof to IP67
- Rugged and impact resistant
- Built for everyday use

Alarm Indication

- 3 levels of instantaneous alarm, time weighted average alarms on toxic
- Periodic confidence flash and bleep
- Increasingly rapid flashing, ultra-bright alarm LEDs
- Powerful two tone audible alarm
- Vibrating alarm for noisy environments*
- Safelink communications*

User Friendly Pre-entry Check

- Peak hold function and drop line
- Hand aspiration
- Built-in automatic pump*
 Tatally flavible
- Totally flexible

*Impact Pro model only



The Impact range of portable multi-gas monitors is able to monitor and display up to four gases simultaneously.

Using high specification flammable, oxygen and patented Surecell[™] toxic sensors, our unique cartridge technology ensures safe, accurate and reliable measurements are always made. Impact and Impact Pro have MED approval.

Available in two configurations, the Impact and Impact Pro accepts either disposable and/or serviceable cartridges respectively, all of which are pre-calibrated and can be replaced in under one minute, so simplifying maintenance and minimising cost wherever possible. Compact and rugged these monitors are designed for tough working environments while being small, lightweight and unobtrusive, making them ideal for use in confined spaces where entry and exit may be difficult. Designed to work how you want to; gas checks prior to entering a confined space can be carried out using a drop line, hand aspirator or via an optional built-in pump (supplied as standard on the Impact Pro) that turns on and off automatically when the sampling tube is connected.

Ultra-bright alarm lights and a powerful audible alarm, coupled with a periodic green flash and bleep provide user confidence that monitoring is always in operation and alarms are never missed. For noisy environments a vibrating alarm is included as standard on the Impact Pro. A large, multilingual, backlit display, with intuitive menu system simplifies use and minimises operator training.

Available for use with a wide range of accessories including the unique Enforcer calibration system and compliance friendly Safelink communication system, you can be sure that the Impact range of portable multigas monitors will be ready to protect you when most needed.



General Specification







lse	Portable multigas monitor for the protection of personnel from up to four hazardous gases in the working environment.
vailable to detect#	Flammable, Oxygen, Carbon Monoxide, Hydrogen Sulfide, Sulfur Dioxide, Chlorine, Nitrogen Dioxide, Ammonia, Carbon Dioxide.
lser interface	Ultra clear, backlit, alphanumeric display. Intuitive push button menu system with user selectable operation in English, French, German, Italian, Spanish and Dutch. Other languages available upon request.
configuration and data download	Supplied configured, ready to use including data-logging as standard. Configurable via optional PC software and base station for control of logging functions and data download.
Construction	Impact resistant plastic, anti-static to EN50014.
limensions	49mm x 84mm x 136mm (1.9" x 3.3" x 5.3")
Veight	Maximum 520g (18oz) including rechargeable battery and optional pump.
P rating	Instrument IP67 (NEMA 4 & 6).
perating temperature [#]	-20°C to +55°C (-4°F to +131°F).
torage temperature [#]	Instrument -40°C to +80°C (-40°F to +176°F).
lumidity range#	Continuous 20 to 90%RH. Intermittent 0-99%RH non-condensing.
larms	3 levels of instantaneous alarm per channel. Time weighted average alarms on toxic channels. Supplied pre-set (user configurable via optional PC software and base station).
udible alarm	Periodic confidence bleep with differing dual tone for fault, gas alarm and warning rated 85dBA at 1m (90dBA at 1ft).
lisual alarm	Green confidence flash with rapid red flashing for fault, gas alarm and warning indication.
lattery performance	Ni-MH rechargeable, operating life $>$ 10 hours (Charging time 7 hours). Dry cell disposable $>$ 17 hours. Nominal reduction of 10% when used with pump.
ptional pump	Supplied as standard with Impact Pro. Typical flow rate 0.31/min. Automatic start/stop feature with auto-test on start-up and flow fail alarm.
pprovals	Europe: Image: Imag
tandard supply	Each instrument is supplied complete with quick start guide, multi-lingual operating instructions on CD, dry cell battery holders and batteries, belt clip and flow adaptor. Fully configured and ready to accept either disposable or serviceable sensor cartridges the key considerations in selecting either the Impact or Impact Pro are highlighted below.
	ImpactImpact ProCartridge type#Disposable onlyDisposable or ServiceableIntegral pump/pump adaptorNoYesVibrating alarmNoYesSafelinkNoYes
rdering information	
ptional accessories	e.g. 2302B1000 9 B E = 2302B10009BE Impact Impact Impact Impact Impact 9 Ima

Our Product Range

Honeywell







Fixed Gas Monitoring

Honeywell Analytics offers a wide range of fixed gas detection solutions for a diverse array of industries and applications including: Commercial properties, industrial applications, semiconductor manufacturers, energy plants and petrochemical sites.

- Detection of flammable, Oxygen and toxic gases (including exotics)
- Innovative use of four core sensing technologies – paper tape, electrochemical cell, catalytic bead and infrared
- Capability to detect down to Parts Per Billion (ppb) or Percent by Volume (%v/v)
- > Cost effective regulatory compliance solutions

Portable Gas Monitoring

When it comes to personal protection from gas hazards, Honeywell Analytics has a wide range of reliable solutions ideally suited for use in confined or enclosed spaces. These include:

- Detection of flammable, Oxygen and toxic gases
- Single gas personal monitors worn by the individual
- Multi-gas portable gas monitors used for confined space entry and regulatory compliance
- Multi-gas transportable monitors used for temporary protection of area during site construction and maintenance activities

Technical Services

At Honeywell Analytics, we believe in the value of great service and customer care. Our key commitment is providing complete and total customer satisfaction. Here are just a few of the services we can offer:

- » Full technical support
- Expert team on hand to answer questions and queries
- Fully equipped workshops to ensure quick turnaround on repairs
- » Comprehensive service engineer network
- » Training on product use and maintenance
- » Mobile calibration service
- Customised programmes of preventative/corrective maintenance
- » Extended warranties on products

Find out more

www.honeywellanalytics.com

Contact Honeywell Analytics:

Europe, Middle East, Africa, India

Life Safety Distribution AG Javastrasse 2 8604 Hegnau Switzerland Tel: +41 (0)44 943 4300 Fax: +41 (0)44 943 4398 India Tel: +91 124 4752700 gasdetection@honeywell.com

Technical Services

EMEAI: HAexpert@honeywell.com US: ha.us.service@honeywell.com AP: ha.ap.service@honeywell.com

www.honeywell.com

Please Note:

While every effort has been made to ensure accuracy in this publication, no responsibility can be accepted for errors or omissions. Data may change, as well as legislation, and you are strongly advised to obtain copies of the most recently issued regulations, standards, and guidelines. This publication is not intended to form the basis of a contract.

H_Impact/Impact Pro_DS0280_V7_EMEAI 05/13 © 2013 Honeywell Analytics

Americas

Honeywell Analytics Inc. 405 Barclay Blvd. Lincolnshire, IL 60069 USA Tel: +1 847 955 8200 Toll free: +1 800 538 0363 Fax: +1 847 955 8210 detectgas@honeywell.com

Asia Pacific

Honeywell Analytics Asia Pacific #701 Kolon Science Valley (1) 43 Digital-Ro 34-Gil, Guro-Gu Seoul 152-729 Korea Tel: +82 (0)2 6909 0300 Fax: +82 (0)2 2025 0329 analytics.ap@honeywell.com

