

testo 310. Fully featured. Priced right. Residential Combustion Analyzer

The simple nature of combustion analysis.

Right the first time - every time.

The testo 310 residential combustion analyzer represents a new class of instruments for Testo and provides exceptional value and expanded capabilities in combustion testing. The 310 sets a new standard in reliable combustion tuning with its rugged housing, simple design and advanced sensor technology.

The **easy-to-read backlit display** shows more measurements which provides a more complete picture of the combustion process. **Simple top-of-display icons** show you the current measurement functions. After only 30 seconds the 310 is ready to test.

Fully featured - for better testing and tuning.

- O₂, CO (w/ NOx filters standard), CO₂
- Draft & Pressure
- Temperature (flue & ambient)
- Combustion efficiency & excess air
- Undiluted CO (CO air free)
- Ambient CO

Simple to use with reliable results.

The testo 310 eliminates the need for look up charts and the purchase and disposal of expensive chemicals. The **kink-resistant hose** is integrated into the housing to eliminate leaks. The stainless steel probe and cone-stop is **perfect for residential furnace, boiler and water heater applications**. With five different fuels to select from, it provides the flexibility you need for your tuning opportunities.

Faster, productive - tune ups, maintenance, and more...

Whether you need to perform basic or more complex combustion tuning, perform maintenance or safety checks, or install new combustion units, the fully featured testo 310 delivers more combustion parameters. Use the 310 for accurate heating adjustment so you can get it right the first time - every time.





More features...more productive.



The new definition of testing and reliability...



Rugged by design The testo 310 can stand up to the toughest job site.



Bright backlit display Five-line backlit display with two-line readout and easy-to-navigate menu structure.



30 seconds to start Start testing faster - in only 30 seconds.



10 hour battery life Work all day with lithium rechargeable battery technology.



Quick exchange probe filter Protect the instrument's measurement accuracy with replacement filters.



Powerful magnets Powerful magnets on the 310's housing allows for hands-free operation.



Condensate trap Quick and easy emptying of the integrated condensate trap.



Wireless printer with integrated magnets For professional job site documentation.



testo 310 combustion kits and accessories.

Includes: analyzer, battery, sensors, probe w/ cone, hose, silicon tubing (for pressure), extra particulate filters (5), AC power supply (USB), pressure plugs (5), calibration certificate, & case.



Product kits	Part no.
testo 310 combustion analyzer kit	0563 3100
testo 310 combustion analyzer kit with printer	0563 3110

Accessories	Part no.
USB power supply incl. cable	0554 1105
Testo IR printer	0554 3100
Testo fast printer IRDA	0554 0549
Spare thermal paper (six rolls)	0554 0568
Spare particle filter	0554 0040

10 hour - Lithium Ion - rechargeable

7.9 x 3.2 x 1.7 in./approx. 1.5 lbs.

Order no. 0563 3100

testo 310 combustion analyzer kit with printer

Includes: all items in kit as shown above (0563 3100) *plus* IR printer (0554 3100), & 2 rolls of thermal paper.



Power

Size/Weight

Storage Temp.

Operating Temp.	23° to 113 °F	
Warranty		
24 mos instrumer	it, sensors, probe	

-4° to 122 °F

12 mos. - thermocouple, rechargeable battery

Order no. 0563 3110

Technical data

Parameter Parameter Measuring range Accuracy **Measuring range** Method 0 to 21 vol.% ±0.2 vol.% CO. 0 - CO, max calculated 0 CO (w/ NOx filter) 0 to 4000 ppm ±20 ppm (0 to 400 ppm) Efficiency 0 - 100% calculated ±1.5% of reading (401 to 2000 ppm) ±10% of reading (2001 to 4000 ppm) Ambient CO ±20 ppm (0 to 400 ppm) Excess Air (EXA) 0 - 100% 0 to 4000 ppm calculated ±1.5% of reading (401 to 2000 ppm) ±20% of reading (2001 to 4000 ppm) 32° to 752 °F ±2 °F (32° to 212 °F) CO Undiluted 0 - 4000 ppm Temperature calculated ±1.5% of reading (>100 °F) (U CO) or - Combustion (0° to 400 °C) (CO Airfree) ±0.01 "H₂O Draft -8 to +8 "H₂O Selectable fuels natural gas; propane; fuel oil 2; bio heat 5; ±1.5% of rdg. (remaining range) wood (w/ 20% moisture) -16 to +16 "H₂O ±0.2 "H₂O Pressure



Distributor:

Testo, Inc. 40 White Lake Road Sparta, NJ 07871 Phone: 800-227-0729 Fax: 862-354-5020 E-mail: info@testo.com

して

www.testo.com